

ENERGY PEN HOLDER

User Manual

Technical Specifications

Input: QC 9V = 2A

Wireless Charging Output: 10W-7,5W-5W


USB Output: 5V = 2A (Max)


Dimension: 88,3 x 98,7 x 88,5 mm

In the box:

- Energy Pen Holder
- Charging cable
- User manual

Product Layout





Indicator light / Type C input / Non-slip Cushion














Once the power supply is connected, the green indicator will flash three times eventually remaining red. When using the wireless charger, the green indicator light will always remain on.

User guide

- Switch the USB cable to any 2A (minimum recommended) power source.
- 2. Place your Qi compatible smartphone on the silicone pad support.
- 3. You can also connect any USB device on its USB Outputs in order to charge or turn them on.



Support WPC Qi V1.2.4 standard

USB Output 1 / USB Output 2 / Pen Holder / Silicone Pad for Phone Standing / Wireless Charging Output Support WPC Qi V1.2.4 standard

Attention:

- Please, do not place any magnetic or metal object between the mobile phone and the wireless charger.
- 2. Wireless charging output takes precedence over USB outputs.
- 3. Please do not place it in a humid or dusty environment.
- 4. A QC Charger (not included) is needed in order to obtain Quick Charge power.

www.ksixmobile.com











When using more than one output simultaneously, its power will be distributed among the connected

Maintenance recommendations

- Regularly clean the product with a dry cloth. The product must be disconnected or switched off when you clean it.
- Keep the connectors and/or ports free from dust, lint, etc. to prevent improper connections.
- Avoid breaking the device. Do not put objects over it or bend it too strong.
- If the product includes a cable do not bend it too strong and do not pull from it to unplug the product.
- Do not wet the product. Keep it always in a dry place, away from humidity.
- When not using the product, store it in a place free from dust, dirt, lint, liquids, etc.
- If water or other liquids enter the product interior, unplug it immediately from any attached power source or device it is connected to.
- Avoid dropping or hitting the product. It might be damaged.
- Do not use the product for anything other than its intended use.
- Please recycle the product in accordance with local environmental laws and regulations.

Safety information

Please read the following instructions before using the device for the first time:

- · When you use device keep it away from heat sources (fire) and from humidity sources (water and other liquids).
- If the product is wet or damaged do not us it.
- Do not use the product with wet hands.
- Do not leave the product in contact with flammable materials.
- Do not expose the product to high temperatures (for example: inside a car during hot weather)
- Do not throw the product into fire.
- Keep the product away from children.
- Disconnect or switch off the product if you are not going to use for a long period of time.
- Do not use the device if you perceive any visible defects.
- Do not attempt to open or puncture the product. You might damage it.
- Do not use the product with incompatible devices.
- Do not dismount or modify the product. These actions will invalidate the Warranty.













Legal Note

Hereby, Atlantis Internacional S.L. declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EC.

The features and functions described in this manual are based on tests made by Atlantis Internacional S.L. It is the user's responsibility to examine and verify the product after its purchase. Atlantis Internacional S.L. is not responsible and will never be liable for any personal loss or injury, economical loss, material loss or any damage due to misuse, abuse or improper installation of the product.

For electronical devices with Bluetooth: Atlantis Internacional S.L. is not responsible and will never be liable for any function, communication and connection failure between the product and Bluetooth enabled devices.

Electronic and electrical devices disposal

This symbol indicates that electrical and electronic equipment is to be collected separately.

Símbolo

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- The final price of this product includes the cost necessary for the correct environmental management of the generated waste.
- If the equipment uses batteries, they must be removed from the equipment and disposed in an appropriate collection center. If the batteries cannot be removed, do not attempt to do it yourself since it must be done by a qualified professional.
- Separate collection and recycling helps conserve natural resources and prevent negative consequences for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

www.ksixmobile.com







